

RECOMMENDED SPARES LIST – THERMOCODE IQ

ESSENTIAL SPARES

KIT REFERENCE: **KIT785300**

	Description	Stock Ref	Qty
1	IQ Rewind Polycord Drive Belt	BEL781127	1
2	Spring Rewind	SPR761152	2
3	Extension Spring	SPR530013	1
4	IQ Ribbon Brake Belt	BEL781126	1
5	Spring Printhead Pressure	SPR762089	2
6	Fuse 7.5a ATO	FUS763029	1
7	Anti Surge Fuse 2a	FUS783020	1
8	Fuse PCB Radial MST250 2a T	FUS783022	1
9	Nip Roller Spring	SPR761099	2
10	Sensor (Generic) **	ELE762092	1

COMPREHENSIVE SPARES

KIT REFERENCE: **KIT785301**

	Description	Stock Ref	Qty
1	IQ Rewind Drive Belt	BEL781127	1
2	Spring Rewind	SPR761152	2
3	Extension Spring	SPR530013	1
4	IQ Ribbon Brake Belt	BEL781126	1
5	Spring Printhead Pressure	SPR762089	2
6	Fuse 7.5a ATO	FUS763029	1
7	Anti Surge Fuse 2a	FUS783020	1
8	Fuse PCB Radial MST250 2a T	FUS783022	1
9	Nip Roller Spring	SPR761099	2
10	Sensor (Generic) **	ELE762092	1
11	Belt Drive (TC2)	BEL762063	1
12	Belt Drive (TC2)	BEL762064	1
13	Horizontal Drive Belt T2.5 X 380	BEL782300	1
14	Motor Drive Board Assembly	ASY782306	3
15	Drive Roller Assembly	ASY761100	1
16	53mm Printhead	PRI762199	1
17	Colibri Board ***	PCB782035	1

Notes

** The sensor mentioned above is generic and the wires will need to be trimmed such that they match the sensor that is to be replaced.

*** The Colibri mentioned above will be supplied with default settings and files only. Customer specific settings and files will need to be added from their back-up.