
## THERMOCODE SERIES 2 (53CL & 107CL) Interconnect Board Wiring Details. (sheet 2)



		_	_	_		_	_	
15	7	14	6	2	9	1	8	D' Connector Pin Numbers
Е	F	G	Н	А	В	С	D	Terminal Block Letter Ref
Orange	Blue	Yellow	Red	Orange	Blue	Yellow	Red	Wire Colour

## NOTES.

- Connect Wires as detailed above

& board support post

6

- Fitting wires around support post.
  2. Fit Cable ties to each set of Motor wires as shown.
  3. Fit Cable tie to terminal wires & board support post.
- 4. Connect the 24 Volt (Red & Black) wires to large terminal block as shown.

Terminal 1 = O volt (Black) Terminal 2 = 24 Volt (Red)

- Connect Printer Body Earth wire to Terminal E1.
   Connect Processor Card (TP12) Earth wire to Terminal E2

0000

0**000** 

 $\Theta$ 

9 

博

(\$O}

0000

 $\bigcirc$ 

000000

(1)

XET /6/106	OPEN DATE EQUIPMENT LID	OPEN DA	CWP CHECKED SCALE 1:1	₩P	DRAWN
PART NO			1014		
,			NONE		FINISH
ETAILS (53C	NTERCONNECT WIRING DETAILS (53CL & 107CL)	NTER	SEE NOTE ABOVE	"	MATERIA
1 477 1		14/4/	ľ	ŀ	
N/A	REASON	MOD No N/A REASON	DATE 17 II IN 2004	_	ISSUE