


REFERENCE DRAWING



NIP ROLLER SENSOR	
1	BLUE
2	BLACK
3	WHITE
4	BROWN

PCB 762442

HOME SENSOR "B"	
1	BLUE
2	BLACK
3	WHITE
4	BROWN

HOME SENSOR "A"	
1	BLUE
2	BLACK
3	WHITE
4	BROWN

HOME SENSOR "A"

RIBBON SENSOR "2"	
1	BROWN
2	BLACK
3	WHITE
4	BLUE

RIBBON SENSOR "1"	
1	BROWN
2	BLACK
3	WHITE
4	BLUE

SUPPLY 24 VOLTS	
1	BLACK "0 volt"
2	RED + 24 volt

EARTHING	
E1	CHASSIS GROUND